




1 FRAME 车架




REF. NO.	PART NO.	PART NAME
1	4UB1-21010-00	Frame
2	4UB1-77302-00	Rubber Set,Seat
3	4UB1-76330-10	Plug
4	4UB1-58171-00	Large Storage Insulation Plate
5	4UB1-58315-00	Brake Pipe Protection Plate
6	GB/T 5789 M8×20	Bolt M8×20 (GB/T 5789)
7	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
8	GB/T 5789 M6×16	Bolt M6×16 (GB/T 5789)
9	4UB1-76873-00	Plug 40×20
10	4UB1-76875-00	Plug 25×40

3


**2 COWLING 导流罩**



REF. NO.	PART NO.	PART NAME
1	4UB1-71114-10	Fixed Hood Latch Hook
2	4UB1-71115-00	Ring
3	4UB1-71112-041	Removable Maintenance Hood Cover (Burgundy Red)
	4UB1-71112-072	Removable Maintenance Hood Cover (Gemstone Blue)
	4UB1-71112-054	Removable Maintenance Hood Cover (Quick sand)
	4UB1-71112-063	Removable Maintenance Hood Cover (Camouflage)
	4UB1-71112-025	Removable Maintenance Hood Cove (Pearl Black)
4	4UB1-71111-025	Removable Decorative Hood
5	Q397A ST4.2	Spring Nut ST4.2 (Q397A)
6	GB/T 845 ST4.2×13	Screw ST4.2×13 (GB/T 845)
7	4UB1-71113-041	Removable Hood (Burgundy Red)
	4UB1-71113-072	Removable Hood (Gemstone Blue)
	4UB1-71113-054	Removable Hood (Quick sand)
	4UB1-71113-063	Removable Hood (Camouflage)
	4UB1-71113-025	Removable Hood (Pearl Black)
8	4UB1-71001-00	Grill Front
9	QC/T 608 M6	Spring Nut M6 (QC/T 608)
10	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
11	GB/T 845 ST4.2×13	Screw ST4.2×13 (GB/T 845)
12	Q397A ST4.2 ST4.2	Spring Nut ST4.2 (Q397A)

**3 FENDER 挡泥板**



REF. NO.	PART NO.	PART NAME
1	4UB1-71171-00	Front Fender, L
2	4UB1-71181-00	Front Fender, R
3	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
4	4UB1-71281-00	Rear Fender, R (Golf version only)
5	4UB1-71261-00	Rear Fender, L (Golf version only)
6	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
7	Q397A ST4.2	Spring Nut ST4.2 (Q397A)
8	GB/T 845 ST4.2×13	SCREW ST4.2×13 (GB/T 845)
9	GB/T 6187.1 M6	Nut M6 (GB/T 6187.1)
10	4UB1-71178-00	Reflecting Film
11	4UB1-80209-00	Rear Tail Light
12	GB/T 973 M4×25	Screw M4×25 (GB/T 973)
13	GB/T 6187.1 M4	Nut M4 (GB/T 6187.1)

**4 DASHBOARD 仪表台**




REF. NO.	PART NO.	PART NAME
1	4UB1-71120-00	Panel, Dashboard
2	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
3	QC/T 608 M6	Spring Nut M6 (QC/T 608)
4	4UB1-71146-00	Steering Wheel Maintenance Cover
5	4UB1-71121-00	Gearshift cover
6	4UB1-86200-00	TFT Multimedia Screen (10")
7	4UB1-71143-00	Glovebox
8	4UB1-77146-00	Glovebox Cushion Rubber
9	4UB1-71147-00	Glovebox Switch
10	4UB1-71144-00	Cup Holder
11	GB/T 973 M5×10	Screw M5×10 (GB/T 973)
12	Screw ST4.2×16	Screw ST4.2×16 (GB/T 845)
13	4UB1-71145-00	Glovebox Mounting Plate
14	GB/T 845 ST4.2×13	Screw ST4.2×13 (GB/T 845)
15	4UB1-71125-00	Parking Handle Dustproof Rubber

16	4UB1-7112200	Meter Cover
17	4UB1-71123-00	Meter Plastic Holder
18	4UB1-71124-00	Middle Glove Box

5 SIDE COVER


侧盖围板



REF. NO.	PART NO.	PART NAME
1	4UB1-71241-00	Seat, Cover Plate, L
2	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
3	4UB1-71113-00	Fixed Hood Ring
4	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
5	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
6	4UB1-71231-00	Seat, Cover Plate, Front
7	QC/T 608 M6	Spring Nut M6 (QC/T 608)
8	4UB1-71242-00	Seat, Cover Plate, R

6 SHAND


脚踏板




REF. NO.	PART NO.	PART NAME
1	4UB1-71252-00	Floor Cover, Foot Rest, Front
2	QC/T 608 M6	Spring Nut M6 (QC/T 608)
3	4UB1-71263-00	Retaining Rubber Clip
4	4UB1-71262-10	Retaining rubber
5	GB/T 96.1 10	Washer 10(GB/T 96.1)
6	GB/T 845 ST4.8×19	Screw ST4.8×19 (GB/T 845)
7	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
8	GB/T 96.1 5	Washer 5(GB/T 96.1)
9	4UB1-71251-00	Foot Plate
10	GB/T 973 M6×16	Screw M6×16 (GB/T 973)

7 CHASSIS SHIELD

底盘护板



REF. NO.	PART NO.	PART NAME
1	4UB1-79261-00	Chassis Protection Plate
2	GB/T 973 M6×16	Screw M6×16 (GB/T 973)
3	4UB1-79221-00	Storage Box
4	4UB1-58808-00	Storage Box Heat Protection Plate
5	GB/T 96.1 8	Washer 8 (GB/T 96.1)
6	4UB1-75521-00	Tool bags
7	GB/T 973 M6×16	Screw M6×16 (GB/T 973)




REF. NO.	PART NO.	PART NAME
1	4UB1-31200-00	Front Shock Strut Body Assy, L
2	4UB1-31400-00	Front Shock Strut Body Assy, R
3	4UB1-31210-00	Front Shock Assy
4	4UB1-31270-00	Bearing35
5	GB/T 893.1 64	Circlip 64(GB/T 893.1)
6	4UB1-31553-00	Brake Disc, Front
7	4UB1-31551-00	Wheel Hub, Front
8	4UB1-32552-00	Bolt
9	GB/T 5783 M8×20	Bolt M8×20 (GB/T 5783)
10	4UB1-31260-00	Oil cup M6
11	4UB1-31240-00	Ball Joint Stud
12	4UB1-31232-00	Coupling Mounting Plate
13	GB/T 819.1 M6×16	Bolt M6×16 (GB/T 819.1)
14	GB/T 9458 M10×1.25	Slotted Nut M10×1.25 (GB/T 9459)
15	GB/T 91 2.5×25	Cotter Pin 2.5×25
16	4UB1-31310-10	A-Arm Welding ,R
17	GB/T 6187.2 M12×1.25	Nut M12×1.25 (GB/T 6187.2)
18	4UB1-31120-00	A-Arm Bushing
19	4UB1-31101-00	A-Arm Pivot Shaft
20	4UB1-31110-10	A-Arm Welding, L
21	4UB1-31420-20	Upper Pivot Ball ASSY
21-1	GB/T 97.1 14	Washer 14 (GB/T 97.1)
21-2	4UB1-31209-00	Cushion Rubber
21-3	4UB1-31202-00	Upper Pivot Ball A
21-4	4UB1-31203-00	Lower Pivot Ball B
22	4UB1-31100-00	A-Arm Assy (Bushing & Rubber) ,L
23	4UB1-31300-00	A-Arm Assy (Bushing & Rubber) ,R
24	GB/T 6187.2 M14×1.5	Nut M14×1.5 (GB/T 6187.2)

25	4UB1-31211-00	Front Shock Spring
----	---------------	--------------------

REF. NO.	PART NO.	PART NAME
1	4UB1-32102-00	Lower A-Arm Axle, Rear
2	4UB1-32103-00	Upper A-Arm Rubber, Rear, L
3	4UB1-32105-00	Lower A-Arm Bushing, Rear, L
4	4UB1-32110-00	Upper A-Arm Welding, Rear, L
5	4UB1-32310-00	Upper A-Arm Welding, Rear, R
6	GB/T 6187.2 M10×1.25	Nut M10×1.25 (GB/T 6187.2)
7	4UB1-32130-10	Lower A-Arm Welding, Rear, L
8	4UB1-32330-10	Lower A-Arm Welding, Rear, R
9	4UB1-32145-00	Upper Hub Bush, Rear
10	4UB1-32143-00	Bolt M10×1.25×135
11	4UB1-32201-00	Bolt M10×1.25×50
12	4UB1-32230-00	Shock absorber ASSY, Rear
13	4UB1-32146-00	Lower Hub Bush, Rear
14	4UB1-32150-00	Seal 61.5 43 12
15	4UB1-32141-00	Carrier Bearing Wheel, Rear
16	4UB1-32170-00	Bearing 34
17	4UB1-3216-000	Seal 58 41.2 12
18	GB/T 893.1 58	Circlip 58(GB/T 893.1)
19	4UB1-32142-00	Bolt M10×1.25×110
20	4UB1-32551-00	Wheel Hub, Rear
21	4UB1-32554-00	Brake Disc, R
22	4UB1-32552-00	Bolt
23	GB/T 5783 M8×20	Bolt M8×20 (GB/T 5783)
24	4UB1-X5514-00	Carrier Bearing Wheel Assy, Rear

9 REAR SUSPENSION SYSTEM 后悬挂系统






10

## FRONT AXLE &amp; FRONT DRIVE SHAFT

前桥组件、前传动轴




REF. NO.	PART NO.	PART NAME
1	4UB1-23500-00	Front Axle Assy
2	4UB1-23700-00	Mounting Plate
3	GB/T 5789 M8×80	Bolt M8×80
4	4UB1-23010-00	Bolt M10×1.25×85
5	GB/T 6187.2 M10×1.25	Nut M10×1.25
6	4UB1-23800-00	Bracket For Vehicle Speed Sensor
7	4UB1-80930-00	Speed Sensor
8	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
9	4UB1-23600-00	Front Drive Shaft
10	M10×1.25×25	Bolt M10×1.25×25
11	GB/T 93 10	Spring Washer φ10
12	GB/T 97.1 10	Flat Washer φ10
13	GB/T 5789 M8×25	Bolt M8×25

11

## REAR AXLE &amp; REAR DRIVE SHAFT

后桥组件、后传动轴




REF. NO.	PART NO.	PART NAME
1	4UB1-23900-00	Rear Axle Assy
2	4UB1-32142-00	Bolt M10×1.25×110
3	M10×1.25	Nut M10×1.25
4	4UB1-23300-00	Rear Drive Shaft
5	M10×1.25×25	Bolt M10×1.25×25
6	GB/T 93 10	Spring Washer φ10
7	GB/T 97.1 10	Flat Washer φ10


12

## STEERING ASSY

操纵系统




REF. NO.	PART NO.	PART NAME
1	4UB1-45520-00	Parking Brake Cable
2	GB/T 5789 M8×16	Bolt M8×16 (GB/T 5789)
3	4UB1-45503-00	Parking Handle Axis
4	4UB1-45502-00	Spring, Parking Handle
5	4UB1-45504-00	Bushing
6	GB/T 6187.1 M6	Nut M6 (GB/T 6187.1)
7	4UB1-45510-00	Parking Handle ASSY
8	GB/T 97.1 12	Washer 12 (GB/T 97.1)
9	GB/T 93 12	Spring Washer 12 (GB/T 93)
10	4UB1-41109-10	Bush B
11	GB/T 5789 M10×1.25×20	Bolt M10×1.25×20 (GB/T 5789)
12	4UB1-41130-00	Column,Steering
13	4UB1-41101-00	Holder, Steering Wheel
14	GB/T 6173 M12×1.25	Nut M12×1.25 (GB/T 6173)
15	4UB1-41110-00	Wheel, Steering
16	GB/T 70.1 M5×20	Screw M5×20 (GB/T 70.1 )
17	4UB1-41102-00	Cover,Steering Wheel




18	GB/T 894.1 16	Circlip 16
19	4UB1-44160-30	Padel, Brake
20	4UB1-44104-00	Spring A, Brake Padel
21	GB/T 91 2.5×25	COTTER PIN 2.5×25
22	4UB1-43103-00	Spring, Throttle
23	4UB1-43140-00	Padel, Throttle

**12 STEERING ASSY 操纵系统**





REF. NO.	PART NO.	PART NAME
24	4UB1-43150-10	Cable, Throttle
25	9350312018261300	Nut M12×1.25 (GB/T 6187.2)
26	4UB1-41107-00	Cushion Rubber of Clip , Steering
27	4UB1-41108-10	Cushion Rubber A
28	4UB1-41120-20	Steering ASSY
29	9401310000031300	Washer 10 (GB/T 97.1)
30	9173310055281300	Bolt M10×1.25×55
31	9383310016261300	Slotted Nut M10×1.25 (GB/T 9459)
32	9330310015261300	Nut M10×1.25 (GB/T 6187.2)
33	4UB1-41170-00	Tie Rod End B
34	4UB1-41106-00	Horn Switch
35	4UB1-51830-00	Steering Wheel Plastic Sleeve
36	9214340060002300	Screw M4×6 (GB/T 818)
37	4UB1-80610-00	Switch Bracket Assembly
38	9402306000031300	Washer 6
39	4UB1-X8061-00	Horn Switch Assembly

**13 FRONT WHEEL 前轮**



REF. NO.	PART NO.	PART NAME
1	4UB1-24503-00	Nut, Wheel
2	4UB1-24560-00	Rim (AL)
3	4UB1-24110-00	Tire F/L, 25×8-12 Off Road
	4UB1-24120-00	Tire F/R, 25×8-12 Off Road





4	4UB1-32540-00	Valve, Rim(TR412)
5	4UB1-X5463-10	Wheel ASSY F/R (AL) 25×8-12 Off Road
6	4UB1-X5461-10	Wheel ASSY F/L (AL) 25×8-12 Off Road
7	GB/T 91 4×32	Cotter PIN 4×32
8	4UB1-24504-00	Slotted Nut M20×1
9	GB/T 1230 20	Washer 20 (GB/T 1230 )
10	4UB1-23106-00	Clamp
11	4UB1-23108-00	Boot
12	4UB1-23109-00	Circlip A
13	4UB1-23400-00	Front Drive Axle ASSY

14

REAR WHEEL

后轮




REF. NO.	PART NO.	PART NAME
1	4UB1-24503-00	Nut, Wheel
2	4UB1-24560-00	Rim (AL)
3	4UB1-24130-00	Tire, R/R25×10-12 Off Road
	4UB1-24140-00	Tire, R/L25×10-12 Off Road
4	4UB1-24540-00	Valve, Rim(TR412)
5	4UB1-X5563-10	Wheel ASSY RR (AL) 25×10-12 Off Road
6	4UB1-X5561-10	Wheel ASSY RL (AL) 25×10-12 Off Road
7	9500340032002300	Cotter Pin 4×32
8	4UB1-24504-00	Slotted Nut M20×1
9	940832000001300	Washer 20 (GB/T 1230 )
10	4UB1-23106-00	Clamp
11	4UB1-23108-00	Boot
12	4UB1-23109-00	Circlip A
13	4UB1-23100-10	Rear Drive Axle ASSY ,L
14	4UB1-23200-10	Rear Drive Axle ASSY ,R

15

## SEAT ASSY

座椅总成




REF. NO.	PART NO.	PART NAME
1	4UB1-51200-10	Head Rest
2	4UB1-51102-10	Pin, Seat ASSY
3	GB/T 5789 M8×16	Bolt M8×16 (GB/T 5789)
4	4UB1-51101-00	Seat Lock
5	4UB1-51100-00	Seat Cushion ASSY
6	4UB1-51310-00	Back Rest
7	GB/T 5789 M6×16	Bolt M6×16 (GB/T 5789)
8	4UB1-54600-00	Folding Arm Rest, R
9	4UB1-54500-00	Folding Arm Rest, L
10	4UB1-52220-10	Headrest Bracket Assy
11	4UB1-52301-00	Mounting Bracket


15

## Speaker Assy

音响




REF. NO.	PART NO.	PART NAME
1	4UB1-86100-00	Bluetooth Speaker
2	4UB1-86101-00	Speaker mounting plate
3	9151306016281300	Bolt M6×16 (GB/T 5783)
4	9330306013241300	Nut M6 (GB/T 6187.1)



REF. NO.	PART NO.	PART NAME
1	4UB1-42620-10	Shift Push Cable, Assy
2	4UB1-42610-20	Front Brake Caliper Body, R
2-1	4UB1-42611-00	Knob Shifter
3	4UB1-42601-00	Alxe Of The Shifter
4	9500325025002300	Cotter Pin 2.5×25

17 ENGINE MOUNTING SYSTEM

发动机安装系统




REF. NO.	PART NO.	PART NAME
1	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
2	4UB1-22150-00	Engine Cushion Rubber
3	4UB1-22110-00	Engine Front Bracket
4	4UB1-22120-00	Gear Box Bracket, L
5	4UB1-22130-10	Gear Box Bracket, R
6	4UB1-22140-00	Engine Front Bracket Sleeve
7	4UB1-22160-00	Bolt M10×1.25×210
8	GB/T 5789 M10×1.25×20	Bolt M10×1.25×20 (GB/T 5789)
9	4UB1-22102-00	Lower A arm mounting shaft, Rear
10	GB/T 6187.2 M10×1.25	Nut M10×1.25 (GB/T 6187.2)

18

## ELECTRICAL SYSTEM

电装品



REF. NO.	PART NO.	PART NAME
1	4UB1-80700-80	Main Wire
2-1	4UB1-80830-20	Wiring Harness For EFI
2-2	4UB1-80830-30	Wiring Harness For EFI (Speed limit version )
3	4UB1-80810-00	Starter Wire 1
4	4UB1-80820-10	Starter Wire 2
5	4UB1-80840-00	Starter Motor Wire
6	4UB1-80520-00	Light Switch
7	4UB1-80530-00	HI / LO Beam Switch
8	4UB1-80550-00	Rear Differential Lock Switch.
9	4UB1-80560-00	Winch Switch
10	4UB1-80540-00	Emergency Alarm Switch
11	4UB1-80580-00	2WD-4WD Switch
12	4UB1-80590-00	Turn Signal Switch
13	4UB1-80880-00	Protector
14	4UB1-80910-00	Reverse Relay ASSY
15	4UB1-80510-00	Ignition Switch
16	4UB1-80640-00	Horn
17	GB/T 5789 M6×16	Bolt M6×16 (GB/T 5789)
18	4UB1-80208-00	Flasher Relay ASSY ( LED )
19	4UB1-81010-00	Battery Belt
20	4UB1-80980-00	Battery (12V 35Ah)
21	4UB1-80320-00	LCD Meter
22	4UB1-80630-00	USB Charger Plug
23	4UB1-80850-00	Parking Switch
24	4UB1-80770-00	Battery wiring sheath
25	4UB1-81471-00	FOUR PORT RELAY


19 BRAKING ASSY

液压制动总成



REF. NO.	PART NO.	PART NAME
1	4UB1-44350-00	Front Brake Hose Assy (Driver Side)
2	4UB1-44320-00	Brake Master Pump ASSY






3	4UB1-44360-00	Front Brake Hose Assy (Passenger Side)
4	GB/T 16674.1 M8×30	Bolt M8×30 (GB/T 16674.1)
5	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
6	4UB1-44327-00	Putter
7	GB/T 91 2.0×25	Cotter Pin 2.0×25
8	4UB1-44506-00	Rubber Cover
9	GB/T 16674.1 M6×12	Bolt M6×12 (GB/T 16674.1)
10	4UB1-44311-00	Hose Clamp
11	GB/T 5783 M8×25	Bolt M8×25 (GB/T 5783)
12	GB/T 93 8	Spring Washer 8 (GB/T 93)
13	GB/T 97.1 8	Washer 8 (GB/T 97.1)
14	4UB1-44420-00	Middle Brake Hose Assy
15	4UB1-44410-00	Rear Brake Hose Assy (Passenger Side)
16	4UB1-44390-00	Rear Brake Hose Assy (Driver Side)
17	4UB1-31553-00	Brake Disc, F
18	4UB1-32554-00	Brake Disc, R
19	4UB1-44330-00	Front Brake Caliper ASSY (Driver Side)
20	4UB1-44340-00	Front Brake Caliper ASSY (Passenger Side)
21	4UB1-44370-00	Rear Brake Caliper ASSY (Driver Side)
22	4UB1-44380-00	Rear Brake Caliper ASSY (Passenger Side)
23	GB/T 818 M5×30	Screw M5×30 (GB/T 818)
24	GB/T 16674.1 M8×22	Bolt M8×22 (GB/T 16674.1)
25	4UB1-44324-00	Main Pump Brake Hose, R
26	4UB1-44323-00	Main Pump Brake Hose, F
27	4UB1-44310-20	Brake Assembly
28	4UB1-44332-00	Inside / Outside pad
29	4UB1-44505-00	Clamps


20

SEAT BELT

安全带




REF. NO.	PART NO.	PART NAME
1	4UB1-53510-00	Safety Belt (3 Point)
2	4UB1-53550-00	Belt Lock Assy
3	4UB1-53501-00	Bolt
4	4UB1-53502-00	Spring Washer




5	4UB1-53503-00	Washer
6	4UB1-53504-00	Nut
7	4UB1-53505-00	Bolt A
8	4UB1-53506-00	Washer
9	4UB1-53507-00	Bolt
10	4UB1-53509-00	Bolt 7/16×35

21 ROPs 保护框组件




REF. NO.	PART NO.	PART NAME
1	4UB1-52100-40	Member,Roof Frame, R
2	4UB1-52400-00	Member,Roof Frame, L
3	4UB1-52200-00	Member, Roof Frame, Front
4	4UB1-52300-00	Member, Roof Frame, Rear
5	M10X1.25X45 (GB/T5789)	Bolt M10×1.25×45
6	GB/T70.1 M10X1.5X45	Bolt M10×1.5×45
7	4UB1-53509-00	Bolt 7/16×35
8	M10X1.5	Nut M10×1.5 (GB/T 6187.2)
9	M10×1.25×16 (GB/T 5789)	Bolt M10×1.25×16 (GB/T 5789)
10	M6×16 (GB/T 5789)	Bolt M6×16 (GB/T 5789)
11	M10×1.25 (GB/T 6187.2)	Nut M10×1.25 (GB/T 6187.2)
12	4UB1-70210-10	Rear View Mirror, R
13	4UB1-70220-10	Rear View Mirror, L
14	4UB1-53504-00	Nut7/16
15		




REF. NO.	PART NO.	PART NAME
1	4UB1-55100-00	Front Bumper
2	GB/T 5789 M8×25	Bolt M8×25 (GB/T 5789)
3	4UB1-76001-00	Plug
4	4UB1-80202-00	Winch Motor Assy
5	4UB1-X8020-20	Winch Relay
6	GB/T 5789 M6×30	Bolt M6×30 (GB/T 5789)
7	GB/T 5789 M8×20	Nut M6 (GB/T 6187.1)
8	4UB1-X8020-21	Cable (Winch Relay - Battery)
9	4UB1-X8020-22	Cable (Winch Relay - Motor)
10	GB/T 16674.1 M8×25	Bolt M8×25(GB/T 16674.1)
11	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
12	GB/T 5789 M6×16	Bolt M6×16(GB/T 5789)

23 Rear stabilizer bar 后横向稳定杆



REF. NO.	PART NO.	PART NAME
1	4UB1-35610-00	Bar ,Stabilizer
2	4UB1-35602-00	Bush.Stabilizer
3	4UB1-35601-00	Clamp, Stabilizer
4	GB/T 5789 M8×20	Bolt M8×20 (GB/T 5789)
5	GB/T 6187.2 M10×1.25	Nut M10×1.25 (GB/T 6187.2)
6	4UB1-35630-00	JOINT, STABILIZER R
7	4UB1-35620-00	JOINT, STABILIZER L


19 Cart Light 前照灯



REF. NO.	PART NO.	PART NAME
1	4UB1-80206-00	Head Light (LED), L
2	GB/T 845 ST4.2×13	Screw ST4.2×13 (GB/T 845)
3	Q397A ST4.2	Spring Nut ST4.2 (Q397A)
4	4UB1-80205-00	Head Light (LED), R


25 Extension Roof (长顶棚)

REF. NO.	PART NO.	PART NAME
----------	----------	-----------



1	4UB1-70602-00	Extension Roof
2	GB/T 16674.1 M8×30	Bolt M8×30 (GB/T 16674.1)
3	4UB1-14402-00	WATER TANK RUBBER CUSHION
4	GB/T 6187.1 M8	Nut M8 (GB/T 6187.1)
5	GB/T 16674.1 M8×40	Bolt M8×35 (GB/T 16674.1)
6	GB/T 16674.1 M8×55	Bolt M8×55 (GB/T 16674.1)
7	GB/T 16674.1 M8×20	Bolt M8×20 (GB/T 16674.1)
8	4UB1-52600-00	Extension Roof mounting Frame
9	4UB1-15101-00	MOUNTING BUFFER RUBBER A
10	4UB1-70603-00	Plain Ø8x30*2
11	GB/T 16674.1 M8×65	Bolt M8×65 (GB/T 16674.1)
12	4UB1-52610-00	Extension roof holder (L)
13	4UB1-52620-00	Extension roof holder (R)

**26 Windshield / Mesh Door 挡风玻璃, 网门**




REF. NO.	PART NO.	PART NAME
1	4UB1-70710-00	Windshield ASSY
2	4UB1-70720-00	Windshield Hold Hoop
3	4UB1-70810-00	Mesh Door (L)
4	4UB1-70820-00	Mesh Door (R)
5	4UB1-70821-00	Safety Net Buckle (右)
6	GB/T 5789 M6×16	FLANGE BOLT M6X16
7	GB/T 6187.1 M6	NUT M6

**27 REAR SEAT ASSY 后排座**



REF. No.	PART No.	PART NAME
1	4UB1-61050-00	Backrest Assy
2	4UB1-61010-00	Rear Passenger, Bracket



3	4UB1-61020-00	Seat cushion
4	4UB1-61021-00	Rear Seat Frame
5	4UB1-61022-00	Rear Seat Frame
6	4UB1-61080-00	Pedal Plate ASSY
7	4UB1-61060-00	Middle Armrest
8	GB/T 5789 M10×1.25×45	Bolt M10×45 (GB/T 5789)
9	GB/T 6187.1 M10×1.25	Nut M8 (GB/T 6187.1)
10	4UB1-61030-00	Support Connecting Tube ASSY
11	GB/T 5789 M8×40	Bolt M8×40 (GB/T 5789)
12	4UB1-86901-00	Reverse Camera
13	4UB1-59700-00	Rear Towing Frame
14	4UB1-61076-00	Pedal, Linkage
15	4UB1-61802-00	Bushing
16	GB/T 16674.1 M8×25	Bolt M8X25(GB/T 5789)
17	4UB1-63001-00	Pin Axle
18	GB/T 623 4×75	B Pin 4×75
19	4UB1-53520-00	Safety Belt (2 Point)
20	GB/T 5789 M8×20	Bolt M8X20(GB/T 5789)
21	4UB1-61040-00	Rear Center Arm rest Holder Assy
22	GB/T 5789 M8×50	Bolt M8×50 (GB/T 5789)
23	GB/T 5789 M8×80	Bolt M8×80 (GB/T 5789)
24	4UB1-61071-00	Rear Foot rest Plate Rack, L
25	4UB1-61072-00	Rear Foot rest Plate Rack, R
26	4UB1-61073-00	Foot rest Dam-board
27	GB/T 973 M6×16	Screw M6×16 (GB/T 973)